



Full Dome Mirrors Installation And Cleaning Instruction

We have suggested two type of installation here, Please Determine which type of installation best suited for your requirements.


Tool Requires : Electric Drill and Mounting Screws (Not Supplied)

1) Screw Mount :

- 1) Position Dome, where you want to install and mark location of the hole. Using drill bit , drill pilot holes.
- 2) Use flat or pan head screws to fasten dome to the ceiling or wall. **Do not draw screws too tightly.** It may crack or break the flange.



SCREW MOUNT



PENDULUM MOUNT

2) Pendulum Mount :

- 1) Install S-hooks (Included) thru pre-drilled holes in dome flange.
- 2) Attach Jack chain (Included) To S -hooks.
- 3) Locate area to place the dome and with screw (Not provided), Attach jack chain to ceiling

Cleaning Instruction

Clean with soft, damp cloth or chamois, wiping gently.

Wash with mild soap or plain water. Use soft cloth or tissue.

DO NOT USE AMMONIA TYPE OR ABRASIVE CLEANING AGENT ON MIRRORS.

3611 Mavis rd # 8-11, Mississauga, L5C 1T7. P: (905) 272-4044 F: (905) 272 -0083